

## **HyperControl Installation for Cubase**

*Note: If Cubase is running, close the application before beginning the HyperControl installation procedure. The instructions below will indicate when Cubase should be launched.*

1. HyperControl technology requires an Axiom AIR “personality” file to be added to one of the Cubase sub-folders. To install this file, run the Axiom AIR Cubase HyperControl installer and follow the on-screen instructions.
2. Once the installation is complete, launch Cubase.
3. Select “Device Setup” from the Device Menu.
4. Select “Remote Devices” from the box on the left side of the window.
5. Click the “+” button at the top-left of the screen and select “M-Audio Axiom AIR”
6. Click the “MIDI Input” drop-down menu and select the “Axiom AIR HyperControl In” Port.
7. Click the “MIDI Output” drop-down menu and select the “Axiom AIR HyperControl Out” Port.

Once the steps above are completed, click “OK.” You can now control Cubase with your Axiom AIR using HyperControl Technology.